

UP radio transmitter - MISTRAL - for mechanical push-buttons

Product number 1249-SE06



Product description

UP radio transmitter - MISTRAL - for mechanical push-buttons

For extending the radio chime 1249-600E-UP with additional buttons, e.g. front door and garden gate.

- **UP radio transmitter type: GROTHE Mistral series**
- Power supply 12 V DC or 1 CR 2450 battery (not included)
- Frequency: 868.35 MHz
- Protection class: IP20 (to be installed in a protected area)

Installation

- 1. install the MISTRAL radio transmitter in a flush-mounted box or the function box behind the existing bell button
- 2. pair the MISTRAL radio transmitter with the radio chime receiver
- 3. by pressing the existing bell button, the radio transmitter sends a signal to the radio chime receiver.

Notes

- Walls, doors, metal parts etc. can noticeably reduce the range!

Dimensions

Width in mm 42

Height in mm 40

Depth in mm 12

More images

